Point Blank Body Armor Sizing			
Size	Chest	Front	Waist
	Measure under the arms, across the shoulder blades and around fullest part of the chest while relaxed (round measurement up to the nearest whole number)	Measure from the clavicle (collar bone) to approx. 1/2 inch above the duty belt (round measurement up to the nearest whole number)	Measure around the fullest part of the torso above the duty belt (round measurement up to the nearest whole number)
Small/Regular	38"-40"	14"-15"	31"-33"
Medium/Regular	42"-44"	14"-15"	34"-36"
Large/Regular	46"-48"	14"-15"	37"-40"
Large/Long	46"-48"	16"	37"-40"
Extra Large/Regular	50"-52"	14"-15"	41"-44"
Extra Large/Long	50"-52"	16"	41"-44"
For additional measuring help, please refer to our product videos			